



Angel Hair or Tails

Problem	Typical Cause	Effect	Action check list	Remark
<p>Found Angel Hair</p> <p>Example : 18/12/14 (Cutter miss alignment)</p>  <p>Example : 9/7/15 (after SU)</p> 	<p><u>Process</u></p> <ol style="list-style-type: none"> Too High Polymer melt temp <ul style="list-style-type: none"> - High After cooler temp - High Barrel Temp Too High Pellet water Temp Too High Die plate Temp Too Low Pellet water Flow <p><u>Mechanical</u></p> <ol style="list-style-type: none"> Cutter defect <ul style="list-style-type: none"> - Gap too high - wear - miss alignment Die plate defect <ul style="list-style-type: none"> - Nip loosen - Orifice crack 	<ol style="list-style-type: none"> Found Angel hair at Sampling point S-5101 Hair that peel out from pellet may cause of PDI19103 increasing and M1910 blockage 	<ol style="list-style-type: none"> Adjust Process Step <p><u>DO!!</u></p> <ul style="list-style-type: none"> Decrease Barrel water; TI17110 ($\downarrow \geq 150$ °C) Increase Pellet water flow; FI17105 ($\uparrow \leq 820$ m3/hr) Decrease After cooler Temp; TIC13099 ($\downarrow \geq 235$ °C) <p><u>DON'T</u></p> <ul style="list-style-type: none"> Don't decrease PEW temp (keep at 40 °C) Don't decrease Die plate Temperature (keep HS header at 37 barg) -----risk of Die freezing----- Adjust Cutter knife <p><u>DO!!</u></p> <ul style="list-style-type: none"> Forward Cutter If Angel hair still found after adjust Step 1 & 2. <p><u>DO!!</u></p> <ul style="list-style-type: none"> Keep monitoring and Report in Daily meeting to find out with TE & AS 	<p><u>After adjusted</u></p> <p>-Monitor each step for 30 min (on site)</p> <p>- If Angel hair still found, do next step</p> <p><u>After adjusted</u></p> <p>-Monitor for 30 min (on site and S-5101 report browser)</p> <p>- <i>Too much forward cutter related to cutter torque high</i></p> <p>- manual SP3A If Can't control product quality and have to judge product to NP</p>